Overview: Lancing device and lancet drum

- **A** Prime and release button
- **B** Lancet counter window
- **C** 11 depth settings
- **D** Lever to change to a new lancet
- **E** 6 preloaded lancets drum

Selecting penetration depth

Select from 11 settings (recommended depth setting is 2).

⚠

The Accu-Chek FastClix lancing device is intended for personal use only.

Inserting a drum

Remove cap.

Insert the lancet drum with the white head pointing to Accu-Chek FastClix lancing device.

Replace cap.

New drum

Used drum

Use all 6 lancets before removing the drum.
The drum cannot be reinserted for hygienic reason.

Obtaining a blood sample

Prime and release in 1-Click action.

Changing lancets

Slide lever back and forth to change to a new lancet. The number above the lever indicates the remaining number of new lancets. Change a new drum only after all the lancets has been used (the number shown 1).

Training video is now available on YouTube:
www.youtube.com/AccuChekMalaysia

Customer care toll-free:
1-800-88-1313

ACCU-CHEK, CLIXMOTION and FASTCLIX are trademarks of Roche.
© 2016 Roche

www.accu-chek.com.my
Roche Diagnostics (M) Sdn Bhd
(231446-P)
2A, Jalan 13/1
46200 Petaling Jaya
Selangor Darul Ehsan
Tel: 03-7955 5039
Fax: 03-7955 5418

Roche

MY_A2RBL_13/01/16

ACCU-CHEK® FastClix

Roche

使用指南
Cara Pakai

ACCU-CHEK®